

Kitchen Instructions

Dishwasher Instructions

1. Upon arrival turn knob clockwise (A)
2. to either 3 min (B) or 10 min (C) wash to heat up (30-40 mins)
3. Load Plastic tray and close door
4. Press start D
5. Drain after last use (turn knob to drain E)
6. Press and hold Start button until empty (F)
7. Check and rinse internal silver trays



Hot Water and Coffee Machine

Takes 45 mins to get to temperature then hot water can be drawn off and coffee brewed

1 jug

makes 7 mugs



1 scoop
of coffee

Button ①

takes 3 mins

2 jugs

makes 14 mugs



2 scoops
of coffee

Button ②

takes 6 mins

3 jugs

makes 21 mugs



3 scoops
of coffee

Button ③

takes 9 mins

After each use please clean as follows:

- Empty coffee filter and replace funnel
- Press Button ①
- Open coffee tap and draw off water into waste jug until it runs clear

Audio Visual Equipment Instructions

The Old Chemist Screen Instructions

Presenting from a Laptop:

1. Turn on Power
2. Connect Laptop to HDMI cable
3. Remote control is kept on top of sound bar
4. Turn Screen on
5. Select **Input** (HDMI 2)
6. To use wireless Laptop clicker (kept in media cupboard) insert UBS (in base) into laptop.
7. Return everything to it's place after use.

INPUT: HDMI 2



The Old Chemist TV Instructions

To use TV:

1. Turn on Power
2. Remote control is kept on top of sound bar
3. Turn on
2. Select **Input**
3. You can sign into any streaming Apps you have the right to use but please log out after use.
4. Please check permission to stream TV or films to an audience

INPUT



The Old Chemist Sound Equipment



To use Bluetooth to play music:
Open the top of green cabinet to the right of the kitchen peninsula (between bar stools and pillar):

1. Turn all three knobs on right hand side to **Media player**
2. Press **Mode** until display states: **BLUE**
3. Pair your phone to: **A Series**
4. Adjust volume with **Media** knob



Fire Alarm Instructions

Fire Alarm Instructions

To stop an audible **FALSE ALARM**:

1. Enter the code **2143** on the control panel
2. Press 'Silence Internal Sounder' (white)
3. Press 'Silence/Resound Sounders' (red)

To turn off lights on panel after alarm has gone off:

1. Enter the code **2143**
 2. Press 'Control panel reset' (green)
- The lights should return to normal.




Table Storage

Table Storage

Please ensure 6 tables are stored as per this photo:

1. Hinges upward to avoid scratching floor
2. Handles outwards to make it easier to pull out
3. Stored end on

To be stored on shelf:

1. Two additional 6ft tables
2. Two 4ft tables
3. Please take care when lifting on and off shelf, two persons advisable - lift at your own risk.

